

APPLICATION LIST MAVIK



MAKE	MODEL	FROM	TO	BLADE
Abarth	500	2007	Today	FT22
Abarth	Grande Punto	2006	Today	FT22
Alfa Romeo	Giulietta	2010	2013	FT22
Alfa Romeo	Mito	2006	Today	FT22
Audi	A1	2010	Today	V66
Audi	A3	2003	2013	V66
Audi	A4	2003	2014	V66
Audi	Q3	2010	Today	V66
Audi	S1	2010	Today	V66
Audi	S3	2005	2013	V66
Audi	TT	2005	2013	V66
Chevrolet	Cruze	2011	2014	VX5
Chevrolet	Orlando	2011	2014	VX5
Chevrolet	Spark	2015	Today	VX5
Chevrolet	Trax	2011	2014	VX5
Chrysler	Ypsilon	2011	Today	FT22
Citroen	Jumper	2012	Today	FT22
Citroen	Nemo	2008	Today	FT22
Citroen	Relay	2012	Today	FT22
Dacia	Duster	2013	2018	VE25
Dacia	Logan	2013	2018	VE25
Dacia	Sandero	2013	2018	VE25
Fiat	500X	2014	-	FT22
Fiat	Tipo	2015	-	FT22
Fiat	Egea	2015	-	FT22
Fiat	500	2007	Today	FT22
Fiat	500L	2012	Today	FT22
Fiat	Bravo	2007	2014	FT22
Fiat	Doblo	2009	Today	FT22
Fiat	Ducato	2012	Today	FT22
Fiat	Fiorino	2008	Today	FT22
Fiat	Grande Punto	2006	Today	FT22
Fiat	Panda	2003	Today	FT22
Fiat	Punto Evo	2011	Today	FT22
Fiat	Qubo	2008	Today	FT22
Fiat	Qubo Van	2008	Today	FT22
Ford (AUS)	B-Series	1999	2001	FD21
Ford (AUS)	B-Series	2001	2004	-
Ford (AUS)	BF Falcon	2005	Today	FD40
Ford (AUS)	Escape	2005	Today	FD21
Ford (AUS)	Explorer	2000	2006	FD21
Ford (AUS)	Explorer Sport Track	1998	2005	FD21
Ford (AUS)	Falcon	1999	2005	FD3
Ford (AUS)	Falcon	2005	Today	FD40
Ford (AUS)	Focus	2000	2004	FD21
Ford (AUS)	Focus	2005	Today	FD40



MAKE	MODEL	FROM	TO	BLADE
Ford (AUS)	Taurus	2004	Today	-
Ford (AUS)	Taurus LX/SHO	1998	1999	FD21
Ford (AUS)	Territory	2004	2005	FD3
Ford (AUS)	Territory	2004	Today	FD40
Ford (AUS)	Tribute	2001	2003	FD21
Ford (BR)	C-Max	2004	2007	FC7
Ford (BR)	Eco-Sport	2003	2007	FC7
Ford (BR)	Fiesta	2003	Today	FC7
Ford (BR)	Fiesta Max	2005	Today	FC7
Ford (BR)	Focus	1998	2007	FD3
Ford (BR)	Ka	2008	Today	FD3
Ford (BR)	Mondeo	2007	2011	FD40
Ford (EU)	C-Max	2003	2010	FD40
Ford (EU)	C-Max (5 seats)	2012	Today	FD40
Ford (EU)	C-Max (7 seats)	2012	Today	FD40
Ford (EU)	Connect	2002	Today	FD3
Ford (EU)	Cougar	1998	2002	FD3
Ford (EU)	Fiesta	2003	2008	FD3
Ford (EU)	Fiesta	2008	Today	FD40
Ford (EU)	Focus	1998	2004	FD3
Ford (EU)	Focus	2004	2010	FD40
Ford (EU)	Focus	2011	Today	FD40
Ford (EU)	Focus SW	2011	Today	FD40
Ford (EU)	Fusion	2002	Today	FD3
Ford (EU)	Galaxy	2006	2010	FD40
Ford (EU)	Galaxy	2011	Today	FD40
Ford (EU)	Kuga	2008	Today	FD40
Ford (EU)	Mondeo	2001	2007	FD3
Ford (EU)	Mondeo	2007	Today	FD40
Ford (EU)	S-Max	2006	Today	FD40
Ford (USA)	500	2005	Today	FD21
Ford (USA)	Crown Victoria	1998	2002	FD21
Ford (USA)	Crown Victoria	2003	Today	FD21
Ford (USA)	Crown Victoria	2007	2011	FD21
Ford (USA)	E-Series	2008	Today	FD21
Ford (USA)	Edge	2007	Today	FD21
Ford (USA)	Escape	2001	2007	FD21
Ford (USA)	Escape	2005	2012	FD21
Ford (USA)	Escape	2008	Today	FD21
Ford (USA)	Excursion	2000	2005	FD21
Ford (USA)	Excursion	2007	Today	FD21
Ford (USA)	Expedition	2003	Today	FD21
Ford (USA)	Expedition	2007	Today	FD21
Ford (USA)	Explorer	1998	2000	FD21
Ford (USA)	Explorer	2000	2006	FD21
Ford (USA)	Explorer	2007	Today	FD21
Ford (USA)	Explorer Sport Track	2001	2010	FD21
Ford (USA)	Explorer Sport Track	2001	2005	FD21
Ford (USA)	F-150	1999	2003	FD21



MAKE	MODEL	FROM	TO	BLADE
Ford (USA)	F-150	2004	Today	FD21
Ford (USA)	F-150	2004	2010	FD21
Ford (USA)	F-250	1999	2003	FD21
Ford (USA)	F-250	2004	Today	FD21
Ford (USA)	F-250	2008	Today	FD21
Ford (USA)	F-350	2004	Today	FD21
Ford (USA)	F-350	2008	Today	FD21
Ford (USA)	F-450	2008	Today	FD21
Ford (USA)	Fiesta	2011	Today	FD21
Ford (USA)	Five Hundred	2005	2007	FD21
Ford (USA)	Flex	2009	Today	FD21
Ford (USA)	Focus	2000	Today	FD21
Ford (USA)	Focus	2006	2011	FD21
Ford (USA)	Freestar	2004	2007	FD21
Ford (USA)	Freestyle	2005	2006	FD21
Ford (USA)	Freestyle	2005	2007	FD21
Ford (USA)	Freestyle	2007	Today	FD21
Ford (USA)	Fusion	2006	Today	FD21
Ford (USA)	GT	2005	2006	FD21
Ford (USA)	Mustang	2005	2012	FD21
Ford (USA)	Mustang	2005	Today	FD21
Ford (USA)	Ranger	1999	2000	FD21
Ford (USA)	Ranger	2001	2010	FD21
Ford (USA)	Ranger	2001	2005	FD21
Ford (USA)	Ranger	2006	2011	FD21
Ford (USA)	Ranger XLT V6	1999	2000	FD21
Ford (USA)	Taurus	1998	2000	FD21
Ford (USA)	Taurus	2000	Today	FD21
Ford (USA)	Taurus	2000	Today	FD21
Ford (USA)	Taurus	2008	2011	FD21
Ford (USA)	Taurus	2012	Today	FD21
Ford (USA)	Thunderbird	2002	2005	FD21
Ford (USA)	Windstar	1999	2000	FD21
Ford (USA)	Windstar	2001	2003	FD21
Ford (USA)	Windstar	2001	2003	FD21
Ford (world)	B-Max	2012	2017	FD40
Ford (world)	C-Max	2003	2010	FD40
Ford (world)	Ecosport	2015	2017	FD40
Ford (world)	Fiesta	2008	2017	FD40
Ford (world)	Focus	2004	2011	FD40
Ford (world)	Galaxy	2006	2015	FD40
Ford (world)	Ka	2007	2016	FD40
Ford (world)	Mondeo	2007	2014	FD40
Ford (world)	S-Max	2006	2015	FD40
Ford (world)	Transit	2012	2016	FD40
Iveco	Daily	2012	Today	FT22
Jeep	Renegade	2014	-	FT22
Jeep	Compass	2016	-	FT22
Lancia	Delta	2008	2014	FT22



MAKE	MODEL	FROM	TO	BLADE
Lancia	Musa	2009	2012	FT22
Lancia	Ypsilon	2011	2012	FT22
Lincoln (USA)	Aviator	2003	2005	FD21
Lincoln (USA)	Blackwood	2002	Today	FD21
Lincoln (USA)	Continental	1998	2002	FD21
Lincoln (USA)	LS	2000	2006	FD21
Lincoln (USA)	Mark LT	2006	2008	FD21
Lincoln (USA)	MKX	2007	2010	FD21
Lincoln (USA)	MKZ	2007	2012	FD21
Lincoln (USA)	Navigator	1998	2002	FD21
Lincoln (USA)	Navigator	2003	2014	FD21
Lincoln (USA)	Town Car	1998	2002	FD21
Lincoln (USA)	Town Car	2003	2011	FD21
Lincoln (USA)	Zephyr	2006	Today	FD21
Mazda (USA)	B Series	1999	2000	FD21
Mazda (USA)	B Series	2001	2004	FD21
Mazda (USA)	B Series	2006	2009	FD21
Mazda (USA)	B Series (Canada)	2010	Today	FD21
Mazda (USA)	Tribute	2001	2006	FD21
Mazda (USA)	Tribute	2008	2011	FD21
Nissan	Micra K14	2016	-	NS34
Nissan	Qashqai	2013	2017	NS34
Nissan	Pulsar	2014	-	NS34
Nissan	X-Trail	2015	-	NS34
Nissan	Juke	2019	-	NS34
Opel/Vauxhall	Adam	2013	2016	VX5
Opel/Vauxhall	Astra	2010	2015	VX5
Opel/Vauxhall	Cascada	2013	2016	VX5
Opel/Vauxhall	Combo	2012	Today	VX5
Opel/Vauxhall	Insignia	2009	2016	VX5
Opel/Vauxhall	Mokka	2012	2016	VX5
Opel/Vauxhall	Zafira	2012	Today	VX5
Opel/Vauxhall	Corsa	2006	2014	VX5
Peugeot	Bipper	2008	Today	FT22
Peugeot	Boxer	2012	Today	FT22
Renault	Traffic III	2014	-	PG33
Renault	Twingo III	2014	-	PG33
Renault	Symbol	2014	-	PG33
Renault	Clio	2003	2007	PG33
Renault	Espace	2003	2010	PG33
Renault	Espace	2014	-	PG33
Renault	Kangoo	2003	2007	PG33
Renault	Kadjar	2015	-	PG33
Renault	Master	2003	2009	PG33
Renault	Modus	2003	2012	PG33
Renault	Megane IV	2015	-	PG33
Renault	Trafic	2002	2013	PG33
Renault	Twingo	2007	2014	PG33
Renault	Velsatis	2002	2005	PG33



MAKE	MODEL	FROM	TO	BLADE
Seat	Altea	2004	2010	V66
Seat	Arosa	2005	2007	V66
Seat	Cordoba	2002	2009	V66
Seat	Ibiza	2004	2009	V66
Seat	Leon	2002	2010	V66
Seat	Toledo	2001	2009	V66
Seat	Vario	2002	2009	V66
Skoda	CityGo	2011	Today	V66
Skoda	Fabia	2001	Today	V66
Skoda	Octavia	2001	2013	V66
Skoda	Roomster	2006	Today	V66
Skoda	Superb	2008	2015	V66
Skoda	Yeti	2009	2017	V66
Smart	ForTwo (453)	2014	Today	PG33
Smart	EQ	2014	Today	PG33
Volkswagen	Bora	1998	2005	V66
Volkswagen	Caddy	2011	Today	V66
Volkswagen	Eos	2006	Today	V66
Volkswagen	Golf 4	1998	2006	V66
Volkswagen	Golf 5	2005	2008	V66
Volkswagen	Golf 6	2009	2012	V66
Volkswagen	Jetta	2006	2011	V66
Volkswagen	Passat	2001	2005	V66
Volkswagen	Polo	2002	2015	V66
Volkswagen	Scirocco	2009	2013	V66
Volkswagen	Sharan	2011	Today	V66
Volkswagen	Tiguan	2007	2013	V66
Volkswagen	Touareg	2010	2015	V66
Volkswagen	Touran	2003	2015	V66
Volkswagen	Transporter T4	2005	2009	V66
Volkswagen	UP!	2011	Today	V66